

Avidbots™ Disc Brush Wear Chart

Fit for your Neo 26" or 32" Disc Cleaning Head models.
With 3 different disc brush options, there is one perfect for your floor!

Tuff Brush (Soft) - White Nylon

- ▶ Ideal for light everyday cleaning and scrubbing to maintain floor cleanliness on most floor materials, including rubber and vinyl flooring.
- ▶ Bristles reach into crevices of hard floors removing dirt without scratching.

NEW



TIME TO REPLACE



Tuff Brush (Medium) - Black Polypropylene

- ▶ Ideal for medium scrubbing and removal of light dirt, scuff marks and residue.
- ▶ Ideal for surfaces that are durable and scratch-resistant.

NEW




TIME TO REPLACE



Grit Brush (Medium) - Green

- ▶ Ideal for heavy-duty scrubbing and removal of dried on residue, saturated grout lines and layers of built up dirt.
- ▶ Flexible enough for cleaning uneven surfaces, however not suggested for fragile flooring.

NEW



TIME TO REPLACE



How To Clean: Remove the brushes and rinse with water to remove debris and entanglements.

When To Replace: Brushes should be replaced when bristles reach 3/4 - 1" or flatten out (whichever occurs first).

▶ For replacement **brushes**, please contact: orders@avidbots.com